

TD 98-065

HGQS02 Test Summary Report

J. DiMarco, S. Feher, D. Orris, J.P. Ozelis,
M. Tartaglia, J.C. Tompkins
(*FNAL*)

November 16, 1998

Contents

1	General Overview	6
1.1	Test Summary Report Outline	6
1.2	Test Overview	7
1.2.1	Test Cycle 1	7
1.2.2	Test Cycle 2	8
2	Quench behavior	9
2.1	Quench history	9
2.1.1	Test Cycle I	9
2.1.2	Test Cycle II	10
2.2	Quench locations	10
3	Quench protection heater study	17
3.1	Quench protection heaters	17
3.2	Strip Heater induced quenches	17
3.3	Spot Heater induced quenches	18
4	Strain Gauge Results	26
4.1	Instrumentation Details	26
4.2	Measurement Schedule	27
4.3	Results	28
5	RRR study	39
A	HGQS01 TEST PLAN	43
A.1	Thermal cycle I	44
A.1.1	Magnetic measurements	44

A.1.2	Room Temperature Pretest/Cooldown	45
A.1.3	At 4.5 K Operation	46
A.1.4	At 1.9K Operation	48
A.2	Thermal cycle II	52
A.2.1	Room Temperature Pretest/Cooldown	52
A.2.2	At 4.5 K Operation	53
A.2.3	At 1.9K Operation	55

List of Figures

2.1	Quench history (qhist.eps)	16
3.1	Heater induced quenches. t_{fn} is plotted as a function of the normalized current. The magnet is protected with inter layer (solid symbol) or outer layer heaters (open symbol) The circle represents the t_{fn} values when AQD signal is used to find the quench initiation time, the square and diamond symbols represent the t_{fn} values when 8 th coil signal is used to find the quench initiation time. For the 8 th coil quench initiation times, a fixed resistance of 33 and 66 $\mu\Omega$ was used as a threshold to indicate the start of a quench.	23
3.2	Quench integral vs. magnet current for spot heater induced quenches. The magnet is protected with inter layer (open symbol) or outer layer heaters (solid symbol), circle symbol: quench integral from time of spot heater quench initiation, triangle symbol: quench integral from time the outer cable detected the quench, square symbol: quench integral from quench detection time, diamonds: quench integral from strip heater voltage onset.	24
3.3	Temperature of outer and inner cable segments vs. the quench integral in MIITs ($10^6 A^2s$) is plotted	25
4.1	Summary of azimuthal coil stress as measured by beam gauges.	33
4.2	Summary of coil end loads after fabrication and during cryogenic operation.	34
4.3	Azimuthal coil stress measured by beam gauges for a run to quench (11400A) at 1.9K.	35

4.4	End loads as measured by bullet gauges for a run to quench (11400A) at 1.9K.	36
4.5	Longitudinal skin strain as measured by skin gauges for a run to quench (11400A) at 1.9K.	37
5.1	Inner coil resistance temperature dependence comparison with parametrization. (rrr1.ps)	41
5.2	Outer coil resistance temperature dependence comparison with parametrization. (rrr2.ps)	42

List of Tables

2.1	Instrumentation settings - spontaneous quenches	11
2.2	QDC settings	11
2.3	Quench history. Test cycle I	12
2.4	Quench history. Test cycle II	13
2.5	Quench files; test cycle I	14
2.6	Quench files, test cycle II	15
3.1	Instrumentation settings - heater induced quenches	19
3.2	Heater induced quench files	20
3.3	Heater induced quench measured quantities. (QI = Quench Integral; t = time to start measuring QI; R = resistance, in = inner cable segment, out = outer cable segment; T = temper- ature)	21
3.4	Strip heater induced quench measured quantities.	22
4.1	Beam Gauges	27
4.2	Bullet Gauges	28
4.3	Capacitance Gauges	29
4.4	HGQS02 Coil Stresses	30
4.5	End loads (in lb)	31
4.6	Coil Stress Changes (-ve = loss)	32
4.7	End load changes (in lb)	32
4.8	Cryogenic Test Results	38

Chapter 1

General Overview

1.1 Test Summary Report Outline

This report presents preliminary results of HGQS02 testing at the FNAL Vertical Magnet Test Facility. HGQS02 is the second 70 mm-aperture, short R&D model LHC quadrupole built at FNAL.

The cold testing overview is presented in chapter 1.

Chapter 2 is devoted to quench performance tests. An overview of quench history is first given, followed by quench start locations. Relevant test conditions and results are given in summary tables.

Heater studies are presented in Chapter 3. Strip and spot heater induced quenches were performed at several different excitation currents and heater voltages at 1.9K. The time delay in quench initiation under these various conditions is presented as a function of the normalized current. We also measured the quench integral as a function of current and a cable segment temperature rise as a function of the quench integral.

Chapter 4 summarizes strain gauge (SG) runs performed throughout the test. Included here are summary sheets of all SG runs, and representative plots of coil stress and end force vs. I^2 (where I is the magnet excitation current) to the highest attainable current at each test temperature. Also included are tables summarizing SG readings at 0 A magnet excitation current (warm, before and after cool down), and plots of stress and end forces vs. time (summarizing SG history for the entire test).

RRR study is summarized in Chapter 5.

1.2 Test Overview

HGQS02 was tested according to the runplan attached as an Appendix to this note. The magnet was placed into the VMTF dewar and it was first cooled down on May 18, 1998, however cold testing began on May 28. The first test cycle ended June 12 with subsequent warm up to room temperature. The second test cycle started on June 27th after cool down to 4.5K and ended on July 3rd. Between the two test cycles the magnet non-lead end preload was set to zero.

1.2.1 Test Cycle 1

Initial cooldown was to 4.5K without restriction on the differences between any of the temperature sensors located in the VMTF dewar. At 4.5K the first spontaneous quench of the magnet occurred at 7365A. Six additional quenches were made at the same 20A/sec ramp rate before proceeding with ramp to quench at 300A/sec. Next the magnet was cooled to 1.9K and strain gauge runs performed. The first 1.9K quench occurred at 9191A - quite low relative to the HGQS02 cable short sample limit. The magnet was quenched twenty-two additional times and then, given the slow training, we decided to do one more spontaneous quench at high ramp rate (300A/sec).

After magnetic measurements, heater studies were made at 1.9K. The magnet was quenched 20 times with various magnet excitation currents and dump delays.

In order to make correlations of "snapshot" events and magnet inductions we made a special run. The quench data logging frequency was changed to a slower rate (0.19Hz) and the magnet was ramped with 100A/sec to 11000A, but at 10665A a quench occurred. The pentek data loggers were still recording snapshot data when the quench occurred so quench data were not saved as a separate file. Due to the lack of high frequency recording of the data, the quench information is pretty poor.

We closed our first test cycle with quench current temperature dependence studies. The magnet was quenched at 3 different temperatures ranging from 1.9K to 2.1K.

During magnet warm up we performed 4 wire resistance measurements to obtain data for RRR studies.

1.2.2 Test Cycle 2

The magnet was cooled down to 4.5K and strain gauge runs were performed. The first quench of TC 2 occurred at 9386 A. Six additional quenches were made: four of them at the same 20 A/sec ramp rate, and two more with higher ramp rates (300A/sec and 150A/sec). The magnet was cooled to 1.9K. Strain gauge runs were performed, and the first quench at 1.9K occurred at 9850A. The magnet was quenched five additional times. Six more heater induced quenches were performed and we warmed the magnet up 4.5K.

At 4.5K we quenched the magnet twice then EIEO measurements were performed.

Chapter 2

Quench behavior

This chapter summarizes the quench behavior of the magnet. Instrumentation settings for the HGQS02 test are summarized in Table 2.1 and Table 2.2; a detailed description of the instrumentation and its configuration is presented elsewhere.

Quench data acquisition was performed using the VMTF (pentek) read-out system with binary quench data stored on a UNIX workstation. The location of the files are on MTF UNIX cluster:

`/vmtf/data/Quench/vmtf.hgqs02/`

The names of the quench files are summarized in Table 2.5 and 2.6. The data were analyzed using the quenchXmgr utility. HGQS02 had about 96 voltage taps, primarily instrumenting the pole turns and wedges on the four inner and outer coil quadrants and inner/outer coil splice regions.

2.1 Quench history

2.1.1 Test Cycle I

HGQS02 was tested according to the run plan attached as an Appendix to this note. The quench history is summarized in Table 2.3 and Table 2.4 and in Figure 2.1. Quench testing began at 4.5K at a ramp rate of 20A/s. The first spontaneous quench current was at 7365A, and the six additional quenches at 20A/s successively increased in quench current; the seventh quench reached 9203A. Since the predicted short sample limit of the superconducting cable

used in this magnet is 10700kA, the quench current obtained is about 14% below that expected. The magnet was then ramped to quench at ramp rate of 300A/s (quench number 8).

The magnet was quenched 23 times (quench numbers 9-31) at 1.9K with the quench current monotonically increasing $\sim 100\text{A} - 300\text{A}$ per quench. The ramp rate for these quenches was 20A/sec. As with 4.5K, the current at quench at 1.9K ceased to increase significantly even though it was twenty-six hundred Amps below the predicted short sample limit of 14100A. Next, ramps to quench at 1.9K were performed at ramp rates of 160A/s, 300A/s, 100A/s, (quench numbers 32-34).

At the end of the first test cycle, 3 additional quenches were taken at temperatures ranging from 1.9K to 2.1K. The magnet was ramped to quench at 20A/sec.

2.1.2 Test Cycle II

The magnet underwent thermal cycle to 300K and was cooled back down to 4.5K. The magnet was quenched seven times at this temperature. The 38th spontaneous quench current (first quench of the second test cycle) was at 9386 A. Since, the next four quench currents were also far below the short sample limit, we quenched the magnet twice more with different ramp rates (300A/sec and 150A/sec) and then we cooled the magnet to 1.9K. At 1.9K the magnet was quenched 6 times (quench number 45 - 50). The 45th (first 1.9K quench of the second test cycle) was at 9850A, which is about 30% below the short sample limit of the cable. Finally, 2 additional quenches were taken at 4.5K. In these studies the magnet was ramped to quench at 20A/sec.

2.2 Quench locations

Voltage taps that instrumented HGQS02 allowed for localization of most quenches. The locations of each spontaneous quench are summarized in Table 2.3.

Most of the spontaneous quenches occurred in the end regions and about 50% of them were at a particular location of the same coil.

Table 2.1: Instrumentation settings - spontaneous quenches

Dump Resistor	Resistance	$60m\Omega$
	Time Delay	$25msec$
Power Supply	Time Constant	$0.5sec$
HFU	Capacitance	$14.4mF$
	Time Delay	$0 - 20msec$
	Voltage	$300V@4.3K$ $350V@1.9K$
Data Logger	Sampling frequency	$7.4kHz$
	Pre-quench window	50%
Current read back	Hollec	

Table 2.2: QDC settings

AQDC name	Threshold settings	Threshold values
Whole coil	1.0	10 V
Whole coil - Idot	0.09	0.9 V
Bucked Half coils	0.06	0.24 V
SC Leads	0.72	0.03 V
Cu Leads	0.74	0.03 V
Ground	1.26	0.1 V

Table 2.3: Quench history. Test cycle I

Quench num	T [K]	dI/dt [A/s]	I_q [A]	Quench location
1	4.5	20	7365	Q2O15a-Q2O16b Le.end - 17% from 16b
2	4.5	20	8654	Q4O15a-Q4O16b Le.end - 42% from 15a
3	4.5	20	8722	Q2O15c-Q2O15d Re.end - 20% from 15d
4	4.5	20	8757	Q4I11c-Q4I11d Re.end - 46% from 11d
5	4.5	20	8897	Q4I11a-Q4I10b Le.end - 46% from 10b
6	4.5	20	8985	Q4I11c-Q4I11d Re.end - 46% from 11d
7	4.5	20	9203	Q3IOrs-Q3O16a Ramp Splice
8	4.5	300	8250	Q1IOrs-Q1I14b Le.end next to Vtap 14b
9	1.9	20	9191	Q4I11c-Q4I11d Re.end - 41% from 11d
10	1.9	20	9401	Q4I11c-Q4I11d Re.end - 42% from 11d
11	1.9	20	9614	Q4I11c-Q4I11d Re.end - 42% from 11d
12	1.9	20	9797	Q4I11c-Q4I11d Re.end - 42% from 11d
13	1.9	20	9999	Q4I11c-Q4I11d Re.end - 48% from 11d
14	1.9	20	10147	Q4I11c-Q4I11d Re.end - 42% from 11d
15	1.9	20	10336	Q4I11c-Q4I11d Re.end - 42% from 11d
16	1.9	20	10523	Q4I11c-Q4I11d Re.end - 42% from 11d
17	1.9	20	10715	Q4I11c-Q4I11d Re.end - 42% from 11d
18	1.9	20	10849	Q4I11a-Q4I10b Le.end - 22% from 11a
19	1.9	20	10852	Q4I11c-Q4I11d Re.end - 41% from 11d
20	1.9	20	11058	Q4I11c-Q4I11d Re.end - 41% from 11d
21	1.9	20	11201	Q4I11c-Q4I11d Re.end - 39% from 11d
22	1.9	20	11317	Q2I14a-Q2I13b Le.end - 45% from 13b
23	1.9	20	11313	Q4I11c-Q4I11d Re.end - 41% from 11d
24	1.9	20	11364	Q2O15c-Q2O15d Re.end - close to Vtap 15d
25	1.9	20	11390	Q2O14b-Q2O14d St.sec. - 49% from 14b
26	1.9	20	11379	Q1I13b-Q1I14c (broken voltage tap)
27	1.9	20	11409	Q4I11c-Q4I11d Re.end - 46% from 11d
28	1.9	20	11398	Q3I10b-Q3I11a Le.end - 45% from 13b
29	1.9	20	11462	Q2I14b-Q2I14d St.sec. - middle
30	1.9	20	11492	Q4I11a-Q4I11b Le.end - 49% from 10b
31	1.9	20	11521	Q4I11c-Q4I11d Re.end - 33% from 11d
32	1.9	160	11335	Q2I10b-Q2IL multiple turn
33	1.9	300	11454	Q3IOrs-Q3I14b Le.end next to Vtap 14b
34	1.9	100	10665	
35	1.9	20	11471	Q2O15c-Q2O15d Re.end
36	1.9	20	11492	Q4I11c-Q4I13b next to Vtap 13b
37	1.9	20	11486	q4I11c-Q4I11d Re.end

Table 2.4: Quench history. Test cycle II

Quench num	T [K]	dI/dt [A/s]	I_q [A]	Quench location
38	4.5	20	9386	Q2O15c-Q2O15d Re.end
39	4.5	20	9366	Q1I13b-Q1I14b
40	4.5	20	9525	Q1I14a-Q1I13b close to 13b
41	4.5	20	9584	Q4I11c-Q4I11d Re.end
42	4.5	20	9781	Q2I13b-Q2I12b close to 13b
43	4.5	300	8405	Q1IOrs-Q1I14b Le.end
44	4.5	150	9787	
45	1.9	20	9850	Q4I11c-Q4I11d Re.end
46	1.9	20	10094	Q4I11c-Q4I11d Re.end
47	1.9	20	10275	Q4I11c-Q4I11d Re.end
48	1.9	20	10453	Q4I11c-Q4I11d Re.end
49	1.9	20	10578	Q4I11c-Q4I11d Re.end
50	1.9	20	10776	Q4I11c-Q4I11d Re.end
51	4.5	20	10714	Q2I11a-Q4I11c St.sec.
52	4.5	20	10795	Q3O16b-Q3O16d St.sec.

Table 2.5: Quench files; test cycle I

Quench num	File name
1	hgqs02.Quench.980528114003.133
2	hgqs02.Quench.980528123540.838
3	hgqs02.Quench.980528133352.998
4	hgqs02.Quench.980528142421.515
5	hgqs02.Quench.980528151609.780
6	hgqs02.Quench.980528154735.498
7	hgqs02.Quench.980528163916.659
8	hgqs02.Quench.980528171531.569
9	hgqs02.Quench.980529140628.419
10	hgqs02.Quench.980529150609.319
11	hgqs02.Quench.980529155256.149
12	hgqs02.Quench.980529170212.996
13	hgqs02.Quench.980529173539.281
14	hgqs02.Quench.980529180919.184
15	hgqs02.Quench.980529184526.454
16	hgqs02.Quench.980529192047.525
17	hgqs02.Quench.980530100606.144
18	hgqs02.Quench.980530110259.031
19	hgqs02.Quench.980530114418.235
20	hgqs02.Quench.980530122228.717
21	hgqs02.Quench.980530132613.729
22	hgqs02.Quench.980530140341.894
23	hgqs02.Quench.980530144532.352
24	hgqs02.Quench.980530153158.702
25	hgqs02.Quench.980530161621.839
26	hgqs02.Quench.980530172249.722
27	hgqs02.Quench.980530181502.919
28	hgqs02.Quench.980603163236.207
29	hgqs02.Quench.980603173117.463
30	hgqs02.Quench.980603183428.824
31	hgqs02.Quench.980603201211.192
32	hgqs02.Quench.980603210827.618
33	hgqs02.Quench.980604150020.659
34	hgqs02.Quench.980612103544.181
35	hgqs02.Quench.980612143000.153
36	hgqs02.Quench.980612150954.316
37	hgqs02.Quench.980612154453.623

Table 2.6: Quench files, test cycle II

Quench num	File name
38	hgqs02.Quench.980629174535.871
39	hgqs02.Quench.980629183228.192
40	hgqs02.Quench.980629195734.266
41	hgqs02.Quench.980629203558.294
42	hgqs02.Quench.980629211359.548
43	hgqs02.Quench.980629215025.493
44	hgqs02.Quench.980629222240.990
45	hgqs02.Quench.980630205029.376
46	hgqs02.Quench.980630212956.111
47	hgqs02.Quench.980630221532.799
48	hgqs02.Quench.980702105029.592
49	hgqs02.Quench.980702113229.480
50	hgqs02.Quench.980702130030.589
51	hgqs02.Quench.980706105939.309
52	hgqs02.Quench.980706122334.858

HGQS02 Quench History

Nominal 4.5K & 1.9K




Figure 2.1: Quench history (qhhist.eps)

Chapter 3

Quench protection heater study

This chapter presents the results of the quench protection heater studies.

3.1 Quench protection heaters

The magnet was instrumented with outer and interlayer strip heaters. Spot heaters were also installed in inner and outer coils. The details of these heaters are described elsewhere. The instrumentation settings are summarized in table 3.1.

3.2 Strip Heater induced quenches

In the strip heater studies, the time delay, t_{fn} (the time from protection heater current initiation to the presence of a detectable quench voltage in the outer coils), was measured as a function of various normalized current values (I/I_c). The result for both the outer and for the interlayer heaters are shown in figure 3.1 and in table 3.4. One can conclude that the interlayer heater is as efficient as the outer heater.

3.3 Spot Heater induced quenches

The main purpose of this study was to measure the quench integral vs. the applied current and the quench propagation velocity during spot heater induced quenches. For most of the quenches the dump was not used to extract the energy. It was delayed for 1 sec. Both interlayer and outer heater were used to protect the magnet. The applied voltage was 400V. No heater delay was applied.

First we determined the minimum voltage to initiate a quench with a spot heater. We increased the voltage in 2 V increments until a quench was observed. 11V was sufficient to initiate a quench.

Then we set the Spot heater firing unit voltage to 25 V and this value was used for all spot heater studies.

The quench integral in MIITs ($10^6 A^2s$) is plotted in Fig. 3.2 as a function of the applied current for quenches induced with the inner spot heaters and protected either with the outer (solid symbols) or interlayer (open symbols) heaters. There are four family of curves; the upper set (circles) represents the quench integral with a starting time at the onset of the spot heater induced resistive voltage (segment label: Q1I14b-Q1IORS), the set labeled with squares is the quench integral with a starting time corresponding to the 300 mV quench detection, the lower set (diamond) represents the quench integral from the onset of voltage growth in the outer coil due to the strip heaters and the set labeled with triangles represents the quench integral with a starting time at the onset of an outer cable segment (across the splice: Q1O16a-Q1IORS) resistive voltage.

Temperature of outer and inner cable segments vs. the quench integral in MIITs ($10^6 A^2s$) is plotted in Fig. 3.3.

Table 3.1: Instrumentation settings - heater induced quenches

Dump Resistor	Resistance	$60m\Omega$
	Time Delay	$25msec$
Power Supply	Time Constant	$0.5sec$
HFU	Capacitance	$14.4mF$
	Voltage	$90 - 400V@1.9K$
Data Logger	Sampling frequency	$7.4kHz$
	Pre-quench window	50%
Current read back	Hollec	

Table 3.2: Heater induced quench files

Quench num	Current [Amps]	temp [K]	Spot heater name & [volt]	Strip heater name & [volt]	File name
1	3000	1.9	innerQ1 11	outer 400	hgqs02.Quench.980609143719.965
2	3000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980609153703.725
3	5000	1.9	innerQ1 11	outer 400	hgqs02.Quench.980609171240.848
4	6000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980609183250.832
5	7000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980610140143.885
6	8000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980610154634.424
7	8000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980610161545.179
8	9000	1.9	innerQ1 25	outer 400	hgqs02.Quench.980610180118.557
9	3000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980610202132.923
10	3000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980610203948.103
11	5000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980610211208.485
12	7000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980610214515.896
13	9000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980610223939.725
14	10000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980611112039.791
15	11000	1.9	innerQ1 25	inter 400	hgqs02.Quench.980611142225.235
16	3000	1.9	outerQ4 25	inter 400	hgqs02.Quench.980612112506.919
17	3000	1.9	outerQ4 25	inter 400	hgqs02.Quench.980612121717.576
18	3000	1.9	outerQ4 25	inter 400	hgqs02.Quench.980612125055.205
19	5000	1.9	outerQ4 25	inter 400	hgqs02.Quench.980612130451.821
20	10500	1.9		inter 400	hgqs02.Quench.980702142930.210
21	10500	1.9		outer 400	hgqs02.Quench.980702164556.406
22	2800	1.9		outer 400	hgqs02.Quench.980702171616.334
23	5600	1.9		outer 400	hgqs02.Quench.980702173434.460
24	2800	1.9		inter 400	hgqs02.Quench.980702175744.381
25	5600	1.9		inter 400	hgqs02.Quench.980702180558.026
26	9500	1.9		inter 400	hgqs02.Quench.980702181522.947

Table 3.3: Heater induced quench measured quantities. (QI = Quench Integral; t = time to start measuring QI; R = resistance, in = inner cable segment, out = outer cable segment; T = temperature)

Quench num	t_{fn} [sec]	QI [MIITs] $t = 0$	QI [MITTs] $t = t_{fn}$	R in [$\mu\Omega$]	R out [$\mu\Omega$]	QI in [MIITs]	QI out [MIITs]	T in [K]	T out [K]
1	0.098	5.00729	4.1648						
2	0.098	5.00174	4.1597	5.6	5.7	12.4	6.95	40.3	34
3	0.050	9.88682	8.67065	22.9	20.2	15.25	11.4	68.4	59.5
4	0.043	11.6362	10.1258	38.0	33.6	16.8	12.7	86.7	75.7
5	0.038	12.9663	11.1477	53.1	49.4	17.7	13.8	103.4	92.1
6	0.033	4.36079	2.33012						
7	0.033	13.9659	11.901	66.6	65.3	18.4	14.6	117.5	107.4
8	0.029	14.7982	12.4924	80.0	80.9	18.8	15.2	131.0	121.7
9	0.060	0.626151	0.0851369						
10	0.060	4.87564	4.35242	5.7	5.6	11.8	6.8	40.5	33.9
11	0.057	9.53642	8.15018	22.8	19.2	15.2	11.1	68.2	58.5
12	0.045	12.4216	10.2692	48.9	44.2	17.1	13.2	99.0	86.7
13	0.032	14.1581	11.6195	74.6	73.5	18.1	14.6	125.5	115.0
14	0.026	14.8108	12.2632	84.0	85.2	18.3	15.0	135.0	125.7
15	0.023	15.4001	12.6626	115.6	122.5	17.0	13.9	165.9	158.5
16	0.060	0.637891	0.199626						
17	0.060	0.638027	0.199671						
18	0.060	4.8404	4.31802						
19	0.057	9.50145	8.11676						

Table 3.4: Strip heater induced quench measured quantities.

Quench num	t_{fn} [sec]	t_{fn} [sec]	t_{fn} [sec]
	ADC signal	8 th coil signal ($33\mu\Omega$)	8 th coil signal ($66\mu\Omega$)
20	0.024	.041	.045
21	0.022	.034	.038
22	0.108	.157	.168
23	0.045	.087	.127
24	0.060	.145	.181
25	0.056	.095	.145
26	0.029	.044	.049

HGQS02 heater time delay




Figure 3.1: Heater induced quenches. t_{fn} is plotted as a function of the normalized current. The magnet is protected with inter layer (solid symbol) or outer layer heaters (open symbol). The circle represents the t_{fn} values when AQD signal is used to find the quench initiation time, the square and diamond symbols represent the t_{fn} values when 8th coil signal is used to find the quench initiation time. For the 8th coil quench initiation times, a fixed resistance of 33 and 66 $\mu\Omega$ was used as a threshold to indicate the start of a quench.




Figure 3.2: Quench integral vs. magnet current for spot heater induced quenches. The magnet is protected with inter layer (open symbol) or outer layer heaters (solid symbol), circle symbol: quench integral from time of spot heater quench initiation, triangle symbol: quench integral from time the outer cable detected the quench, square symbol: quench integral from quench detection time, diamonds: quench integral from strip heater voltage onset.

HGQS02 Quench integral vs. Temperature




Figure 3.3: Temperature of outer and inner cable segments vs. the quench integral in MIITs ($10^6 A^2 s$) is plotted

Chapter 4

Strain Gauge Results

4.1 Instrumentation Details

Magnet HGQs02 is instrumented with an assortment of strain gauges to measure azimuthal coil stresses and coil end forces. These strain gauges are calibrated at room temperature and at liquid Helium temperature, are read out during various phases of the magnet construction process, and during cryogenic testing.

A total of eight beam-type strain gauges are used to measure azimuthal stresses in the straight section of the coils, four mounted at the inner coils, four mounted at the outer coils. Each active strain gauge has a compensating gauge associated with it, whose purpose is to provide an independent measure of the apparent strains induced in the active gauges due to thermal contraction and magneto-resistance effects.

Four capacitance-type strain gauges were also installed in the straight section of the inner coils to measure azimuthal stress. Each of these gauges were installed in such a way that they were in the same collared coil cavity as one of the inner coil beam gauges. Additionally, four capacitance gauges were mounted on the end saddles of the coils to monitor pre-stress during assembly and cryogenic operation.

A total of eight bullet-type gauges are used to measure the end forces associated with each inner/outer coil pair. Four bullet gauges are mounted at the return-end of the magnet, while four are mounted at the lead end. Each bullet gauge consists of two strain gauges whose readings are subsequently

averaged to eliminate strains resulting from bending of the transducer structure. The resultant strain is then used to compute the force on the bullet. Two compensating gauges are placed at each end of the magnet, whose readings are averaged in order to provide apparent strain data used in eliminating apparent strains from the active gauges.

Table 4.1 I gives the list of coil azimuthal strain gauges, names, and locations for magnet HGQS02, while Table 4.2 lists the same information for the bullet gauges, and Table 4.3 lists this information for capacitance strain gauges.

Table 4.1: Beam Gauges

Gauge ID	Type	Coil	Function	Quadrant	End	VMTF Name
LHCI003	Beam	Inner	Active	Quad 2	LE	BmAcQ2IL
LHCI004	Beam	Inner	Active	Quad 4	LE	BmAcQ4IL
LHCI005	Beam	Inner	Active	Quad 2	RE	BmAcQ2IR
LHCI006	Beam	Inner	Active	Quad 4	RE	BmAcQ4IR
LHCTC02	Beam	Inner	Comp	Quad 2	LE	BmCoQ2IL
LHCTC04	Beam	Inner	Comp	Quad 4	LE	BmCoQ4IL
LHCTC05	Beam	Inner	Comp	Quad 2	RE	BmCoQ2IR
LHCTC07	Beam	Inner	Comp	Quad 4	RE	BmCoQ4IR
LHCO005	Beam	Outer	Active	Quad 1	LE	BmAcQ1OL
LHCO004	Beam	Outer	Active	Quad 3	LE	BmAcQ3OL
LHCO007	Beam	Outer	Active	Quad 1	RE	BmAcQ1OR
LHCO008	Beam	Outer	Active	Quad 3	RE	BmAcQ3OR
LHCTC08	Beam	Outer	Comp	Quad 1	LE	BmCoQ1OL
LHCTC10	Beam	Outer	Comp	Quad 3	LE	BmCoQ3OL
LHCTC11	Beam	Outer	Comp	Quad 1	RE	BmCoQ1OR
LHCTC13	Beam	Outer	Comp	Quad 3	RE	BmCoQ3OR

4.2 Measurement Schedule

Strain gauge readings are performed several times during the magnet construction and testing cycles. Azimuthal coil stresses, measured with beam-

Table 4.2: Bullet Gauges

Production Gauge Nam	VMTF Gauge Nam	Gauge Type	Gauge Location	Remarks
BL09A/B	BuQ1R	Bullet, active	Quad 1, RE	
BL10A/B	BuQ4R	Bullet, active	Quad 4, RE	
BL11A/B	BuQ2R	Bullet, active	Quad 2, RE	
BL12A/B	BuQ3R	Bullet, active	Quad 3, RE	
BL13A/B	BuQ1L	Bullet, active	Quad 1, LE	
BL14A/B	BuQ2L	Bullet, active	Quad 2, LE	
BL15A/B	BuQ3L	Bullet, active	Quad 3, LE	
BL16A/B	BuQ4L	Bullet, active	Quad 4, LE	
BT26	BuCoR_1	Bullet, comp.	RE	Comp. for RE bullets
BT30	BuCoR_2	Bullet, comp.	RE	“
BT28	BuCoL_1	Bullet, comp.	LE	Comp. for LE bullets
BT29	BuCoL_2	Bullet, comp.	LE	”

type and capacitance strain gauges, are measured during the collaring and yoking/skinning assembly procedures. After the end plates are installed onto the magnet cold mass, the bullet gauges are then installed and the end loading screws torqued to achieve the desired end loads, while the bullet gauges are monitored.

Once cold mass fabrication has been completed, the magnet is moved to the magnet test facility, and prepared for cryogenic testing. Before, during, and after cryogenic testing all strain gauges are monitored. In particular, strain gauge data is acquired while ramping the magnet before and during quench training at 4.5K and 1.9K. Finally, the strain gauges are read out once the cold mass has been warmed back up to room temperature, so that comparisons with pre-cold test data can be made.

4.3 Results

The azimuthal coil stresses as measured by beam gauges are summarized in Table 4.4, which shows the coil stresses (measured in psi) during various

Table 4.3: Capacitance Gauges

Gauge ID	Coil	Function	Quadrant	End	VMTF Name
HQCGI16	Inner	Active	Quad 1	LE	CgAcQ1IL
HQCGI19	Inner	Active	Quad 3	LE	CgAcQ3IL
HQCGI30	Inner	Active	Quad 1	RE	CgAcQ1IR
HQCGI32	Inner	Active	Quad 3	RE	CgAcQ3IR
HQCGR34	Saddle	Active	Quad 2-3	LE	CgAcQ23SL
HQCGR35	Saddle	Active	Quad 2-3	RE	CgAcQ23SR
HQCGL36	Saddle	Active	Quad 1-4	RE	CgAcQ14SR
HQCGL37	Saddle	Active	Quad 1-4	LE	CgAcQ14SL

fabrication and operational conditions. End loads for the coils (in lbs) are likewise given in Table 4.5. Figure 4.1 shows the azimuthal coil stress history of the cold mass during fabrication, through yoking/skinning in ICB, and at various cryogenic conditions. Figure 4.2 shows the same data for the coil end loads.

In Figures 4.3, 4.4 and 4.5 we show the results of strain gauge, bullet gauge, and skin gauge measurements as a function of I^2 for a quench run to 11201A at 1.9K. Note that the azimuthal coil stresses remain non-zero for all values of excitation current. There is no evidence of coil unloading at even the highest current level reached. Furthermore, extrapolation indicates that the lowest pre-loaded coil would only reach zero azimuthal stress at currents above 13.4 kA, somewhat below the conductor limit at 1.9K, but well above the designed operating current.

The plot of end loading (Fig. 4.4) indicates that though the initial end loads at 300K were between 1600 and 3000 lbs/quadrant, the coils were essentially unloaded at cryogenic temperatures. In fact, only one coil (Quad 4, Lead End) appeared to be in contact with the end plate at liquid helium temperatures with no current in the magnet. The other quadrants made contact with the end plate only after significant current was applied (see Table 4.5); indeed at 4.5K, and hence, lower maximum currents, some coils failed to contact the end plate at all before a quench occurred (e.g., quadrants 2 & 3, both ends). Furthermore, it was noted that the effects of training on the longitudinal position of the coils were not reversible - the onset of contact

Table 4.4: HGQS02 Coil Stresses
Condition

Gauge	300K, Yoked	300K, VMTF	4.5K, I=0	4.5K, I=9203A	1.9K, I=0	1.9K, I=11409A
Q2IL	2902	3350	7644	4424	7879	2227
Q2IR	13869	13740	13580	9415	13754	7145
Q4IL	7969	8270	9893	6657	10042	4659
Q4IR	9763	10820	11605	8080	12309	6055
Average	8626	9045	10681	7144	10996	5022
Q1OL	9549	BAD	BAD	BAD	BAD	BAD
Q1OR	15791	16141	16680	14808	17600	14194
Q3OL	10428	11040	9527	7861	10894	7687
Q3OR	13044	13600	10370	9109	10897	8695
Average	12203	13594	12192	10593	13130	10192

with the end plates occurred at lower currents for subsequent quenches. Between test cycles, the end loading screws at the return end were completely loosened to ensure that the coils would not contact the return end plates at any operating current, in order to determine the effects of longitudinal restraint on training. No effect was observed.

The skin gauges indicated marginal levels of skin stress as a function of I^2 (Fig. 4.5) not inconsistent with that expected if the total end loads as measured by the bullet gauges were to be transferred to the shell at the end plate. The gauge mounted closest to the return end measured a skin strain that was somewhat higher than indicated by end loading considerations, but not by a significant amount.

The plots shown in Figures 4.3-4.5 are typical of all of the quench runs at 4.5K and 1.9K. No anomalous behavior was observed during cryogenic testing. Additional data/plots can be found on the Web at <http://mdtf20.fnal.gov/~ozelis/HGQS02>. The dynamic mechanical behavior of magnet HGQS02 is summarized in Table 4.8. This behavior is very similar to that of magnet HGQS01, yet the quench locations and behavior were significantly different. It would appear that the mechanical behavior described by these data is de-coupled from the mechanism that is

Table 4.5: End loads (in lb)

Bullet	Condition						1.9K	4.5K
	300K, Yoked	300K, VMTF	4.5K, I=0A	4.5K, I=9203A	1.9K, I=0A	1.9K, I=11409A	Load starts (A)	Load starts (A)
Q1R	2850	2250	-890	-475	-198	920	6320	7420
Q2R	3288	2700	-1033	-866	-408	467	8950	> 9200
Q3R	2848	2300	-1133	-931	-117	521	8775	> 9200
Q4R	2572	3000	-940	-734				8660
Total	11558	10250	-3996	-3006	-723	1908		
Average	2890	2563	-999	-752	-181	477		

Q1L	1914	1920	-1005	-294	-344	1190	5000	6600
Q2L	2050	1600	-1068	-903	-240	797	8000	> 9200
Q3L	1920	1600	-1084	-841	-247	886	8180	> 9200
Q4L	1975	1650	-1029	30	-154	1822	0	3500
Total	7859	6770	-4186	-2008	-985	4695		
Average	1965	1693	-1047	-502	-246	1174		

responsible for the quenches/training in magnet HGQS02.

Table 4.6: Coil Stress Changes (-ve = loss)

Gauge	Condition				4.5K 0 - 9203 A	1.9K 0 - 11409 A
	Yoked-VMTF (300K)	VMTF (300K-4.5K)	VMTF (300K-1.9K)	VMTF (4.5K-1.9K)		
Q2IL	448	4294	4529	235	-3220	-5652
Q2IR	-129	-160	14	174	-4165	-6609
Q4IL	301	1623	1772	149	-3236	-5383
Q4IR	1057	785	1489	704	-3525	-6254
Average	419	1636	1951	316	-3537	-5975
					-4.17E-05	-4.59E-05
					(psi/A ²)	(psi/A ²)
Q1OL						
Q1OR	350	539	1459	920	-1872	-3406
Q3OL	612	-1513	-146	1367	-1666	-3207
Q3OR	556	-3230	-2703	527	-1261	-2202
Average	506	-1401	-463	938	-1600	-2938
					-1.89E-05	-2.26E-05
					(psi/A ²)	(psi/A ²)

Table 4.7: End load changes (in lb)

Bullet	Condition				4.5K 0 - 9203 A	1.9K 0 - 11409 A	Δ Force/ kA ²	Δ Force/ kA ²
	Yoked-VMTF (300K)	VMTF (300K-4.5K)	VMTF (300K-1.9K)	VMTF (4.5K-1.9K)				
Q1R	-600	-3140	-2448	692	415	1118	1.24E-05	
Q2R	-588	-3733	-3108	625	167	875	1.75E-05	
Q3R	-548	-3433	-2417	1016	202	638	1.20E-05	
Q4R	428	-3940			206			
Total	-1308	-14246	-7973	2333	990	2631		
Average	-327	-3562	-2658	778	330	877	1.40E-05	1.60E-05
Q1L	6	-2925	-2264	661	711	1534	1.46E-05	
Q2L	-450	-2668	-1840	828	165	1037	1.57E-05	
Q3L	-320	-2684	-1847	837	243	1133	1.80E-05	
Q4L	-325	-2679	-1804	875	1059	1976	1.52E-05	
Total	-1089	-10956	-7755	3201	2178	5680		
Average	-272	-2739	-1939	800	545	1420	1.58E-05	1.70E-05

Figure 4.1: Summary of azimuthal coil stress as measured by beam gauges.

Figure 4.2: Summary of coil end loads after fabrication and during cryogenic operation.

HGQS02 – Coil Stress

Beam Gauges – Fast Scan to Quench (11409 A) @ 1.9K




Figure 4.3: Azimuthal coil stress measured by beam gauges for a run to quench (11400A) at 1.9K.

HGQS02 – End Loads

Bullet Gauges – Fast Scan to Quench (11409 A) @ 1.9K




Figure 4.4: End loads as measured by bullet gauges for a run to quench (11400A) at 1.9K.

HGQS02 – Skin Stress

Shell Gauges – Fast Scan to Quench (11409 A) @ 1.9K




Figure 4.5: Longitudinal skin strain as measured by skin gauges for a run to quench (11400A) at 1.9K.

Table 4.8: Cryogenic Test Results

	measured	predicted
Average Inner Coil Cool-Down Gain	1600 – 1900 psi (11 – 13 MPa)	600 psi (4 MPa)
Average Outer Coil Cool-Down Loss	500 – 1400 psi (3 – 10 MPa)	1450 psi (10 MPa)
Average Inner Coil Lorentz Loss	$4.2 - 4.6 \times 10^{-5} psi/A^2$ ($2.9 - 3.2 \times 10^{-7} MPa/A^2$)	$4.4 \times 10^{-5} psi/A^2$ ($3.0 \times 10^{-7} MPa/A^2$)
Average Outer Coil Lorentz Loss	$1.9 - 2.3 \times 10^{-5} psi/A^2$ ($1.3 - 1.6 \times 10^{-7} MPa/A^2$)	$2.9 \times 10^{-5} psi/A^2$ ($2.0 \times 10^{-7} MPa/A^2$)
Average Lead End Lorentz Loss	$1.7 \times 10^{-5} lbf/A^2$ ($7.6 \times 10^{-5} N/A^2$)	$8.2 \times 10^{-5} lbf/A^2$ ($3.6 \times 10^{-4} N/A^2$)
Average Return End Lorentz Loss	$1.6 \times 10^{-5} lbf/A^2$ ($7.1 \times 10^{-5} N/A^2$)	$8.2 \times 10^{-5} lbf/A^2$ ($3.6 \times 10^{-4} N/A^2$)
Skin Strains (1.9K, 11409 A)	RE08 : $18 \pm 4\mu\epsilon$; RE70 : $9 \pm 4\mu\epsilon$	Based on total RE load expect 5 – 6 $\mu\epsilon$
	RE27 : $7 \pm 4\mu\epsilon$; RE82 : $12 \pm 4\mu\epsilon$	
	RE41 : $10 \pm 4\mu\epsilon$; RE96 : bad	
	RE54 : $7 \pm 4\mu\epsilon$; RE109 : $11 \pm 4\mu\epsilon$	

Chapter 5

RRR study

This chapter summarizes the residual resistance ratio (RRR) measurements. RRR is determined by measuring the coil resistance and temperature during magnet warm up.

Measurements of magnet resistance were made using a 4-wire technique at a current of 10A. Current was supplied by a Hewlett Packard Power Supply and voltages measured through the magnet voltage taps (see chapter 1). Both voltage and current measurements were made using HP3458A DMMs. For measurement of temperature we used Carbon-Glass sensors in the vicinity of the magnet. Two sensors were used, one of them closer to the top of the magnet and the other closer to the bottom. Note that these sensors were in fact reading the gas temperature and therefore one would expect the actual magnet temperature to be somewhat different.

Figures 5.1 and 5.2 compare the resistances of the eighth coils, measured while the magnet was gradually warming up, against the calculated room temperature resistances. For these plots, the average temperature of the top and bottom carbon glass sensors was used. We observed that the parameterization curve constrained by the resistance values measured at the lower temperatures does not agree well with the data measured at the higher temperatures. However, the magnet resistance around 10 K is not temperature dependent and therefore the error in RRR introduced by basing measurements on these points is not significant ($< 10\%$).

Note that the RRR value for the inner coil (~ 225) is significantly larger than that of the outer coil (~ 95). This is not necessarily a surprise since the inner and outer cable strands are made from completely different billets. It

also interesting to point out that HGQS01 cable RRR value was about 1.6 times lower than HGQS02 cable RRR value. This might be due to a different coil curing process.




Figure 5.1: Inner coil resistance temperature dependence comparison with parametrization. (rrr1.ps)




Figure 5.2: Outer coil resistance temperature dependence comparison with parametrization. (rrr2.ps)

Appendix A

HGQS01 TEST PLAN

Thermal Cycle I

- Magnetic measurements
- Room Temperature Pretest and Cool down
RRR
- At 4.5K Operation
Pre-Current excitation Checkout
2500 amp Heater test
Strain gauge runs
Quench Plateau (max. 5 quenches)
Ramp Rate Studies
- At 1.9K Operation
Pre-current excitation Checkout
3000 amp Heater tests
Strain gauge runs
Quench Plateau
Ramp rate studies
Magnetic measurements

Heater studies (outer, interlayer, spot heater)
Quench Current vs. temperature
RRR

Thermal Cycle II

- Room Temperature Pretest and Cool down
- At 4.5K Operation
 - Pre-Current excitation Checkout
 - 2500 amp Heater test
 - Quench Plateau (max. 5 quenches)
 - Ramp Rate Studies
- At 1.9K Operation
 - Pre-current excitation Checkout
 - 3000 amp Heater tests
 - Strain gauge runs
 - Quench Plateau
 - Ramp rate studies
 - Heater studies (outer, interlayer, spot heater)
 - Energy loss measurement
 - Quench Current vs. temperature
 - RRR

A.1 Thermal cycle I

A.1.1 Magnetic measurements

1. Without Yoke
2. With Yoke

3. In the dewar (optional)
 - (a) Locate magnetic center by scanning ends
 - (b) Apply ± 10 A. Take measurements at 8 different z locations. At each z step make 25 rotations. Take these readings with “amplifiers in”.

A.1.2 Room Temperature Pretest/Cooldown

1. Follow Present procedures for Strain gauge, voltage taps, thermometer, and heater validation. Procedures include:
 - (a) Hi pot the magnet in gaseous He environment. Maximum volts should not exceed V_{max} value (to be determined).
 - (b) 4 wire measurement of all strain gages
 - (c) 5 amps across magnet, measure voltage across taps Measure magnet resistance and compare it to the value measured at IB3. Verify that there are no shorts in the magnet
 - (d) 4 wire heater resistance, system resistance for all four heaters.
2. Record at least 10 strain gage readings at room temperature, check values with post assembly readings.
3. Set strain gage and thermometer readings to 10 minute intervals
4. Place 5 amps through magnet, measure voltage across magnet (each eighth coils separately).
5. Cool down to 80K, then change strain gage and thermometer readings to 1 minute intervals. Cool to 4.5 K , 1.1 ATM with unrestricted cooldown following VMTF cool-down procedure and take volage readings for RRR studies (make sure to get data around ~ 10 K). Take Strain gauge runs as well. Verify that no shorts appeared during cooldown.

A.1.3 At 4.5 K Operation

1. Cold electrical tests prior to magnet testing
 - (a) Check magnet resistance to ground
 - (b) Hi pot (1.1 ATM helium). Maximum volts should not exceed V_{max} value (to be determined).
 - (c) Make sure that strain gauge readings are recorded
 - (d) Protect magnet with a 60 m Ω dump resistor. $I_{max} * R_{dump} \leq 1000V$
 - (e) Heater Pretests
 - i. Configure QLM to fire heater with 1 sec dump firing delay
 - ii. Check outer and inter-layer heater and heater system resistance using 4 wire techniques. System capacitance should be set to approximately 14.4 mF.
 - iii. Verify that inter-layer and outer heaters are wired in parallel check system continuity
 - iv. Fire inter-layer heaters from VMTF program. Verify RC, V heaters, I heaters from data logger plots
 - (f) Disable Digital QDC (or set to high thresholds)
 - (g) Balance quench detection circuitry for analog QDC
 - i. Set dump delay to 0 sec
 - ii. sawtooth ramps between 50 A and 200 A at 100 A/sec.
 - iii. Establish thresholds based on observed noise versus anticipated signals.
 - (h) Balance quench detection circuit for DQDC
 - (i) Set dump delay to 20 msec and the heater delay to 0msec. Manual trip at 1000 A. **Every single analog QDC platform has to be checked separately. Power supply, dump switch, heater and interlock respond should follow the proper quench logic.** Delay heater firing to 1 sec dump delay = 0 sec. Do another manual trip and check L/R, look at all data logger voltage signals; compare V_{max} to $I * R_{dump}$

2. Quench Heater Protection test

- (a) Set dump resistor delay to 0 ms, no heater delay, no power supply phase off delay
- (b) At 2500A magnet current, determine voltage required to quench heaters with $t_{fn} < 200$ ms
- (c) If MIITS o.k dump delay to 20 ms, delay heater firing to 0 ms
- (d) Check quench logic signal for proper quench timing sequence

3. Strain gauge run

- (a) Dump resistor set to 60 m Ω , 20 ms delay , delay heater to 0 ms, heater value as perr 0.2.3 2.b
- (b) At Ramp rate = 20 A /sec. :
Measure the inductance of the magnet. Make sure to run “snapshot” script. Take strain gauge runs, one file per current loop, using the sequences of currents below.
 - i. Run 1: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 7100 A and from 7100 A to 0 A. Disable “fast strain gauge” script.
 - ii. Run 2: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 8400 A and from 8400 A to 0 A. Disable “fast strain gauge” script.
 - iii. Run 3: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 9000 A and from 9000 A to 0 A. Disable “fast strain gauge” script. 9000 A
 - iv. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 9500 A and from 9500 A to 0 A. Disable “fast strain gauge” script. 9500 A
 - v. Run 5: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10000 A and from 10000 A to 0 A. Disable “fast strain gauge” script. 10000 A
 - vi. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10500 A and from 10500 A to 0 A. Disable “fast strain gauge” script. Note: After Run 1, expect quench during strain gage run

4. Quench plateau.

Before each quench measure the inductance of the magnet. Make sure that the inductance remain unchanged. With ramp rate = 20 A/sec, train the magnet. Do not do more than 5 quenches. The predicted short sample limit currents (inner coil) is 10340 A. Make sure to run “fast strain gauge” and “snap-shot” scripts.

5. RAMP RATE dependence studies.

Ramp to quench at 300 a/s, 150 a/s,

A.1.4 At 1.9K Operation

1. Cold Electrical tests prior to current excitation Repeat section 0.2.3 1.c,d,e

2. Quench Heater Protection Test Repeat Section 0.2.3 2.a,b,c,d with 3000A applied current.

3. Strain gauge run

(a) Repeat Section 0.2.2 4.a

(b) At Ramp rate = 20 A /sec. :

Measure the inductance of the magnet. Make sure to run “snap-shot” script. Take strain gauge runs, one file per current loop, using the sequences of currents below.

- i. Run 1: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10000 A and from 10000 A to 0 A. Disable “fast strain gauge” script.
- ii. Run 2: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 11000 A and from 11000 A to 0 A. Disable “fast strain gauge” script.
- iii. Run 3: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 11800 A and from 11800 A to 0 A. Disable “fast strain gauge” script.
- iv. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 12700 A and from 12700 A to 0 A. Disable “fast strain gauge” script.

- v. Run 5: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 13400 A and from 13400 A to 0 A. Disable “fast strain gauge” script.
- vi. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 14200 A and from 14200 A to 0 A. Disable “fast strain gauge” script. Note: After Run 1, expect quench during strain gage run

4. Quench plateau.

With ramp rate = 20 A/sec, train the magnet until 4 plateau quenches have occurred. Do not do more than 15 quenches (only if magnet shows interesting behavior). The predicted short sample limit currents (inner coil) is 13900 A. Make sure to run “fast strain gauge” and “snap-shot” scripts.

5. RAMP RATE dependence studies.

Ramp to quench at 300 A/sec, 200 A/sec, 150 A/sec, 100 A/sec, 75 A/sec, 50 A/sec

6. Magnetic measurements

The default ramp rate is 20 A/sec.

The nominal data set is 25 rotations of the coil.

All measurement sequences should begin with a “cleansing” quench at ~ 10000 A. A cleansing quench is done by firing the magnet heaters with magnet current high enough to produce a small remnant field.

- (a) Set the heater delay to 0 sec, dump delay to 20 msec, and dump resistance to $60\text{ m}\Omega$.
- (b) Determine the minimum magnet current for a cleansing quench: check the effect of a cleansing quench at 10000 A by checking the remnant magnetic field. If the remnant field is substantial increase the current and quench the magnet again. Repeat this procedure until the minimum current is found. Use this value of the current for all cleasing quenches needed for this test plan.
- (c) Remove pre-amplifiers used for warm measurement if this has not already been done.

- (d) Set magnet measurement coordinate system as per TD-98-xxx. File the completed note with this run plan.
- (e) Z scans: take measurements at 8 different z locations along the length of the cold mass.
 - i. Make Z scan at 2000 A
 - A. Estimate magnet center and compare to the predicted value.
 - ii. Make Z scan at 6000 A
 - iii. Make Z scan at $I_{quench} - 500$ A
- (f) End scans (lead end): move the probe by 2 cm increments and at each step take a measurement. Begin outside of the magnet. Make sure to cover ± 30 cm of the end region (at least 30 z positions).
 - i. Make end scan at 2000 A
 - ii. Make end scan at $I_{quench} - 500$ A
- (g) Make a “hysteresis loop” measurement at magnet center (t.b.d.): make three consecutive loops from I_{min} to $I_{quench} - 500$ A with continuous measurement. We define I_{min} as a current near to the injection current; I_{quench} is the quench plateau current reached following training .
- (h) Make a standardization cycle (see Fig. ??) measurement: ramp to flattop current, $I_{plateau} = I_{quench} - 500$ A, dwell at $I_{plateau}$ for t_{dwell} ramp down to 50 A, dwell for 2 sec, ramp to 800 A; wait $t_{injection}$, then ramp to $I_{quench} - 500$ A at 20 A/sec. Default parameters are $I_{plateau} = I_{quench} - 500$ A; $t_{dwell} = 30$ min.; $t_{injection} = 30$ min.
- (i) Analyze the data from the standardization cycle measurement. If “dynamic effects” are seen in the data, the following measurements will be made. (Wait to perform these measurements UNTIL the data have been analyzed, if necessary, continuing the measurement program with item (j).)
 - i. Repeat the standardization cycle with different $I_{plateau}$. The other parameters remain the same.
 - ii. Repeat the standardization cycle with yet a different $I_{plateau}$. The other parameters remain the same.

- iii. Pick an $I_{plateau}$ from the above list and repeat the standardization cycle with a different t_{dwell} .
- iv. Pick an $I_{plateau}$ from the above list and repeat the standardization cycle with a different $t_{injection}$.
- (j) DC loop (“stairstep” loop): Take continuous measurements during the loop. Stop for 2 min. at each of the following currents: 0, 1000, 2000, 3000, 4000, 5000, 6000, ... $I_{quench} - 500$ A on both the up ramp and down ramp.
- (k) Repeat the hysteresis loop of (g) with different ramp rates: 10 A/sec, 40 A/sec, 80 A/sec.
- (l) Repeat the hysteresis loop of (g) at 2 different z positions (t.b.d.)

7. Heater studies at 1.9K

- (a) Set dump resistor delay to 20 ms, no heater delay, no power supply phase off delay or delay it within MIITs limit (12 MIITs)
- (b) Outer Heater study
 - i. At $I/I_c = 0.2$ magnet current determine Vmin for quench. Fire heaters at additional voltage values: 225, 250, 300, 400. DO NOT EXCEED MAXIMUM HFU VOLTAGE
 - ii. $I/I_c = 0.4$ determine Vmin for quench. 200, 250, 300, 400 . DO NOT EXCEED MAXIMUM HFU VOLTAGE
 - iii. $I/I_c = 0.7$ determine Vmin for quench. 110, 150, 250, 300, 400. DO NOT EXCEED MAXIMUM HFU VOLTAGE
 - iv. $I/I_c = 0.9$ determine Vmin for quench Fire heaters at additional voltage values: 90, 150, 250, 300, 400. DO NOT EXCEED MAXIMUM HFU VOLTAGE
- (c) Interlayer heater study. Repeat outer heater study.
- (d) Spot heater study
 - i. At $I/I_c = 0.2$ magnet current determine Vmin for quench.

- ii. $I/I_c = 0.4$ determine V_{min} for quench.
 - iii. $I/I_c = 0.7$ determine V_{min} for quench.
 - iv. $I/I_c = 0.9$ determine V_{min} for quench.
- (e) Quench Current vs. temperature

Ramp magnet to quench at 20 a/s at the following temperatures
 1.8K, 2.1K, 2.7K, 3.2K, 3.7K, 4.2K
 should not be exact value (± 0.2 K)
- (f) RRR measurement

Perform 4 wire measurement using DMM. The applied current should be 5amps and applied only during data taking. Take reading in every couple hours, however make sure that there is a measurement taken when the magnet temperature is between 15 - 20 K.

A.2 Thermal cycle II

A.2.1 Room Temperature Pretest/Cooldown

1. Follow Present procedures for Strain gauge, voltage taps, thermometer, and heater validation. Procedures include:
 - (a) Hi pot the magnet in gaseous He environment. Maximum volts should not exceed V_{max} value (to be determined).
 - (b) 4 wire measurement of all strain gages
 - (c) 5 amps across magnet, measure voltage across taps Measure magnet resistance and compare it to the value measured at IB3. Verify that there are no shorts in the magnet
 - (d) 4 wire heater resistance, system resistance for all four heaters.
2. Record at least 10 strain gage readings at room temperature, check values with thermal cycle I readings.
3. Set strain gage and thermometer readings to 10 minute intervals
4. Verify that no shorts appeared during cooldown.

A.2.2 At 4.5 K Operation

1. Cold electrical tests prior to magnet testing
 - (a) Check magnet resistance to ground
 - (b) Hi pot (1.1 ATM helium). Maximum volts should not exceed V_{max} value (to be determined).
 - (c) Make sure that strain gauge readings are recorded
 - (d) Protect magnet with a 60 m Ω dump resistor. $I_{max} * R_{dump} \leq 1000V$
 - (e) Heater Pretests
 - i. Configure QLM to fire heater with 25 msec dump firing delay
 - ii. Check outer and inter-layer heater and heater system resistance using 4 wire techniques. System capacitance should be set to approximately 14.4 mF.
 - iii. Verify that inter-layer and outer heaters are wired in parallel check system continuity
 - iv. Fire inter-layer heaters from VMTF prgram. Verify RC, V heaters, I heaters from data logger plots
 - (f) Disable Digital QDC (or set to high tresholds)
 - (g) Balance quench detection circuitry for analog QDC
 - i. Set dump delay to 0 sec
 - ii. sawtooth ramps between 50 A and 200 A at 100 A/sec.
 - iii. sawtooth ramps between 50 A and 400 A at 300 A/sec.
 - iv. Establish thresholds based on observed noise versus anticipated signals.
 - (h) Balance quench detection circuit for DQDC
 - (i) Set dump delay to 25 msec and the heater delay to 0msec. Manual trip at 1000 A. **Every single analog QDC platform has to be checked separately. Power supply, dump switch, heater and interlock respond should follow the proper quench logic.** Delay heater firing to 1 sec dump delay = 0 sec. Do another manual trip and check L/R, look at all data logger voltage signals; compare V_{max} to $I * R_{dump}$

2. Quench Heater Protection test

- (a) Set dump resistor delay to 25 ms, no heater delay, no power supply phase off delay
- (b) At 2500A magnet current, determine voltage required to quench heaters with $t_{fn} < 200$ ms
- (c) If MIITS o.k dump delay to 25 ms, delay heater firing to 20 ms
- (d) Check quench logic signal for proper quench timing sequence

3. Strain gauge run

- (a) Dump resistor set to 60 m Ω , 25 ms delay , delay heater to 20 ms, heater value as perr 0.2.3 2.b
- (b) At Ramp rate = 20 A /sec. :
Measure the inductance of the magnet. Make sure to run “snapshot” script. Take strain gauge runs, one file per current loop, using the sequences of currents below.
 - i. Run 1: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 7100 A and from 7100 A to 0 A. Disable “fast strain gauge” script.
 - ii. Run 2: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 8400 A and from 8400 A to 0 A. Disable “fast strain gauge” script.
 - iii. Run 3: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 9000 A and from 9000 A to 0 A. Disable “fast strain gauge” script. 9000 A
 - iv. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 9500 A and from 9500 A to 0 A. Disable “fast strain gauge” script. 9500 A
 - v. Run 5: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10000 A and from 10000 A to 0 A. Disable “fast strain gauge” script. 10000 A
 - vi. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10500 A and from 10500 A to 0 A. Disable “fast strain gauge” script. Note: After Run 1, expect quench during strain gage run

4. Quench plateau.

Before each quench measure the inductance of the magnet. Make sure that the inductance remain unchanged. With ramp rate = 20 A/sec, train the magnet. Do not do more than 5 quenches. The predicted short sample limit currents (inner coil) is 10340 A. Make sure to run “fast strain gauge” and “snap-shot” scripts.

5. RAMP RATE dependence studies.

Ramp to quench at 300 a/s, 150 a/s,

A.2.3 At 1.9K Operation

1. Cold Electrical tests prior to current excitation Repeat section 0.2.3 1.c,d,e

2. Quench Heater Protection Test Repeat Section 0.2.3 2.a,b,c,d with 3000A applied current.

3. Strain gauge run

(a) Repeat Section 0.2.2 4.a

(b) At Ramp rate = 20 A /sec. :

Measure the inductance of the magnet. Make sure to run “snap-shot” script. Take strain gauge runs, one file per current loop, using the sequences of currents below.

- i. Run 1: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 10000 A and from 10000 A to 0 A. Disable “fast strain gauge” script.
- ii. Run 2: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 11000 A and from 11000 A to 0 A. Disable “fast strain gauge” script.
- iii. Run 3: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 11800 A and from 11800 A to 0 A. Disable “fast strain gauge” script.
- iv. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 12700 A and from 12700 A to 0 A. Disable “fast strain gauge” script.

- v. Run 5: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 13400 A and from 13400 A to 0 A. Disable “fast strain gauge” script.
 - vi. Run 4: Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to 14200 A and from 14200 A to 0 A. Disable “fast strain gauge” script. Note: After Run 1, expect quench during strain gage run
- 4. Quench plateau.

With ramp rate = 20 A/sec, train the magnet until 4 plateau quenches have occurred. Do not do more than 15 quenches (only if magnet shows interesting behavior). The predicted short sample limit currents (inner coil) is 13900 A. Make sure to run “fast strain gauge” and “snap-shot” scripts.
- 5. Enable “fast strain gauge” script. Ramp the magnet with 20 A/sec ramp rate from 0 A to $I_{plateau} - 100A$, and from $I_{plateau} - 100A$ to 0 A. Disable “fast strain gauge” script.
- 6. RAMP RATE dependence studies.

Ramp to quench at 300 A/sec, 200 A/sec, 150 A/sec, 100 A/sec, 75 A/sec, 50 A/sec
- 7. Heater studies at 1.9K
 - (a) Set dump resistor delay to 25 ms, no heater delay, no power supply phase off delay or delay it within MIITs limit (12 MIITs)
 - (b) Outer Heater study
 - i. At $I/I_c = 0.2$ magnet current determine V_{min} for quench. Fire heaters at additional voltage values: 225, 250, 300, 400. DO NOT EXCEDE MAXIMUM HFU VOLTAGE
 - ii. $I/I_c = 0.4$ determine V_{min} for quench. 200, 250, 300, 400 . DO NOT EXCEDE MAXIMUM HFU VOLTAGE

- iii. $I/I_c = 0.7$ determine V_{min} for quench.
110, 150, 250, 300, 400. DO NOT EXCEED MAXIMUM
HFU VOLTAGE
- iv. $I/I_c = 0.9$ determine V_{min} for quench Fire heaters at additional voltage values:
90, 150, 250, 300, 400. DO NOT EXCEED MAXIMUM HFU
VOLTAGE

(c) Interlayer heater study. Repeat outer heater study.

(d) Spot heater study

- i. For protection use interlayer heaters. Set SHFU=400V and 0msec delay. At $I/I_c = 0.9$ fire the outer spot heater with the following Dump delays:
30 msec, 40 msec, 50 msec, 60 msec
- ii. Repeat the above with $I = 10000$ A.
Make sure the quench integral value is within the 15 MIITs limit!

8. If time permits: Energy loss measurement (at 1.9K) Ramp the magnet up to 10000A from 500A wait 5 sec then ramp down. Repeat this at least three times. Monitor coil voltages.

Change the ramp rate between 30 - 300 A/s (30A/s, 50 A/s, 100 A/s, 150 A/s, 200 A/s, 250 A/s, 300 A/s)

9. Quench Current vs. temperature

Ramp magnet to quench at 20 a/s at the following temperatures

1.8K, 2.1K, 2.7K, 3.2K, 3.7K, 4.2K

should not be exact value (± 0.2 K)

10. RRR measurement

Perform 4 wire measurement using DMM. The applied current should be 5amps and applied only during data taking. Take reading in every couple hours, however make sure that there is a measurement taken when the magnet temperature is between 15 - 20 K.